

CarAlarm MetaService



TIPO DI AUTOMOBILE/PLA: ED ANNO DI PRODUZIONE:

OPEL VECTRA 2002

SCHEDA NUMERO

28.26

LOCATION OF THE CAR ALARM CONTROL UNIT

Compact control units and sirens: Place under the bonnet behind the headlamp on the wheel hub on driver's side.

Control units and accessories: place under the dashboard on driver's side.

CAR ALARM SUPPLY

Positive: connect to a connection point in the fuse box.

Negative: connect to the manufacturer's predetermined connection point.

IMMOBILISER

Starter motor: Cut the **Black/Red** wire in the cable that exits the control unit under the bonnet near the battery.

Fuel pump: Cut the **Red/Dark Blue** wire (pos. n°3) in the Black 33-pin connector C1 section in the main control unit in the boot on driver's side.

MILEOMETER

Connect to the **Light Blue/Red** wire (pos. n°18) in the 25 pin connector on the ABS control unit located on the support for the shock absorber on driver's side.

POSITIVE IGNITION KEY (+15)

Connect to a positive sub key taking care that it is also present during ignition.

ENABLING PASSIVE ARMING (Connection with an alarm that can be armed with vehicle's original remote control)

Follow the instructions for connection in **FILE 28.26.1**

DIRECTION INDICATORS

Separate controls for each set of lights.

Connect to the **Black/White** wire (front LEFT pos. n°3), **Black/White** wire (side LEFT pos. n°4), **Black/Green** wire (front RIGHT pos. n°2), **Black/Green** wire (side RIGHT pos. n°9) in the Black -pin connector in the control unit under the bonnet near the battery, **Black/White** wire (rear LEFT pos. n°8), **Black/Green** wire (rear RIGHT pos. n°9) in the Dark Blue 33-pin connector D1 section in the main control unit in the boot on driver's side.

Separate the lines with diodes.

DOORS PROTECTION

Connect to the **Brown/White** wire on the standard ceiling light.

N.B. Timed control of switch off.

BONNET/BOOT PROTECTION

Bonnet: install the switch supplied in the box.

Boot: Connect to the **Black** wire (pos. n°6) in the Grey 33 -pin connector section in the main control unit in the boot on driver's side.

ELECTRIC WINDOWS

The windows are lifted with the comfort function by lengthening the time for closing to 25".

Negative-type controls.

Use the M162 module.

Connect to the **Red/Yellow** wire (pos. n° 25) in the Black 46 -pin connector on the control unit inside the driver's door.

CarAlarm MetaService



TIPO DI AUTOMOBILE/PLA E DATA DI PRODUZIONE:

OPEL VECTRA 2002

SCHEDA NUMERO

28.26.1

METHOD OF INSTALLATION FOR M750/2

FUNCTION	COLOUR OF M750 WIRE	COLOUR OF VEHICLE WIRE	POSITION OF WIRE ON VEHICLE
Arming command	RED/BLACK	BLACK/YELLOW (pos. n°17)	Black 46-pin connector on control unit inside driver's door.
Disarming command	RED/WHITE	BLACK/RED (pos. n°15)	Black 46-pin connector on control unit inside driver's door.
Inhibition	LIGHT BLUE/YELLOW	RED/YELLOW (pos. n°25)	Black 46-pin connector on control unit inside driver's door.
Inhibition	RED/YELLOW	See diagram	

