

CarAlarm MetaService



TIPO DI AUTOMOBILE/PLA: ED ANNO DI PRODUZIONE:

RENAULT CLIO 2001

SCHEDA NUMERO

31.30

LOCATION OF THE CAR ALARM CONTROL UNIT

Compact control units and sirens: place under the bonnet next to the battery

Control units and accessories: place under the dashboard on driver's side

CAR ALARM SUPPLY

Positive: connect to the manufacturer's predetermined connection point

Negative: connect to the manufacturer's predetermined connection point

IMMOBILISER

The vehicle is supplied with an original transponder engine immobiliser that arms automatically by removing the ignition key from the ignition switch

POSITIVE IGNITION KEY (+15)

Connect to the **Yellow/Purple** wire (**pos. A4**) in the White 15 pin connector in the control unit under the dashboard on driver's side.

CENTRAL DOOR LOCKING (Connection with remote controlled alarm)

Negative-type controls.

Connect the wire for opening and the wire for closing from the alarm to the **Pink** wire (**pos.n°36**) in the Black 40 pin connector in the control unit under the dashboard on driver's side

ENABLING PASSIVE ARMING (Connection with an alarm that can be armed with vehicle's original remote control)

Follow the instructions for connection in **FILE 31.30.1.**

DIRECTION INDICATORS

Connect to the **White/Brown** (**pos. A3**) and the **Purple/Brown** (**pos. A2**) wires in the Black 15 pin connector in the control unit under the dashboard on driver's side.

DOORS PROTECTION

Connect to the **Green** wire (**pos.n° 40**) in the Black 40 pin connector in the control unit under the dashboard on driver's side.

BONNET/BOOT PROTECTION

Bonnet: install the switch supplied in the box

Boot: Connect to the **Green** wire (**pos.n° 39**) in the Black 40 pin connector in the control unit under the dashboard on driver's side.

ELECTRIC WINDOWS

System with negative polarity at rest, only cut the wires that provide positive polarity when lifting the windows.

Front left: Cut the **Purple** wire (positive for closing) in the White connector in the control unit under the dashboard on driver's side.

Front right: Cut the **White/Orange** wire (positive for closing) and **Grey/Orange** wire located in the cabling which exits the driver's door.

CarAlarm MetaService



TIPO DI AUTOVEICOLI: FILIALE: ED ANNO DI PRODUZIONE:

RENAULT CLIO 2001

SCHEDA NUMERO

31.30.1

INSTALLATION FILE FOR M750/1 POSITIVE set up

FUNCTION	COLOUR OF M750 WIRE	COLOUR OF VEHICLE WIRE	POSITION OF WIRE OF VEHICLE	
Arming command	RED/BLACK	GREEN	Pos.A4	Black 15-pin connector on control unit under the dashboard on driver's side.
Disarming command	RED/WHITE	WHITE	Pos.A6	Black 15-pin connector on control unit under the dashboard on driver's side.
Inhibition of arming	PALE BLUE/YELLOW	PINK	Pos.36	Black 40-pin connector on control unit under the dashboard on driver's side
Inhibition of disarming	RED/YELLOW			

